

# Raise Boring Rig RBR300VF

- > For long raises and large reaming diameters
- > Robust and powerful design
- > Mechanized rod handling for improved work safety
- > Highly efficient variable frequency drive





# Raise Boring Rig RBR300VF Technical specifications

**The Raise Boring Rig (RBR)** developed by Herrenknecht is designed for the construction of shafts in rock down to 2,000 meters in depth. Thanks to its compact design, it offers high flexibility even under space constraints and is therefore suitable for various applications in the mining industry. It has proven its worth with its modular design and its efficient center-free drive. Connection shafts for mining or penstocks for pump storage power plants can be constructed quickly and safely.



Transport system



Pipe handling



Control cabin

#### RBR300VF

- > Reaming torque: 250kNm (184,000lbf.ft)
- Max. static torque: 350kNm (258,000lbf,ft)
- > Thrust force: 4,500kN (1,011,000lbf)
- > Inclination (from vertical): 0°-45°

#### **Dimensions**

- Height (extended/retracted): 6.84 m/4.12 m (22.44 ft/13.54 ft)
- ) Width: 1.87 m (6.14ft)
- ) Depth: 2.4 m (7.87 ft)

### Weight

> Rig: 23.5t (51,808lb)

#### Hoist unit

> Stroke: 2.3 m (7.55ft)

Modular design for high degree of flexibility.

## PIPE HANDLER

- ) Load: 800 kg (1,763 lb)
- ) Handling system: mechanized
- ) Optional: axial drill rod adjustment

#### **WRENCH SYSTEM**

> Handling system: fully hydraulically operated

Mechanized drill rod handling and wrench system for safe and easy handling.

#### **MAIN DRIVE**

- > Drive: electric (VF)
- Number of motors: 1
- Installed power: 250 kW (335hp)
- / installed power: 250kW (335hp)
- Rotational speed (pilot drilling): 0rpm-50rpm
  Rotational speed (reaming): 0rpm-15rpm
- > Hydraulic drive system: on request

Variable speed and torque limiting control.

#### DRIVEHEAD

- > Float: 60 mm (2.36 inch)
- ) Swivel: ±1°

Drivehead with swivel and float function saves drill rod threads.

#### **DRILL ROD**

- ) Diameter: 11¼ inch
- ) Optional diameter: 12% inch
- ) Length, s/s: 1.524 m (60 inch)
- ) Other sizes: on request

#### **HYDRAULIC POWER PACK**

Power: 75 kW (100 hp)Cooling: water-cooled

#### **ELECTRIC POWER PACK**

- ) Input voltage: 400 V
- > Frequency: 50 Hz/60 Hz

#### **CONTROL CABIN**

> Controls: touch screen and control panel

#### **OPTIONAL EQUIPMENT**

#### Tools

- ) Digital Drilling Report
- > High pressure flushing pump
- > Transformer
- › Pipe Feeder
- > Transport frame
- Control cabinet
- ) Chiller system
- > Flow meters> Drilling tools
- > Other tools on request

#### Crawle

- > Drive: diesel powered hydraulic drive
- > Power: 55 kW (74 hp)
- ) Grade: max. +25%
- Optional: forklift equipment

Crawler for quick and easy movement and erection of the rig.

# HERRENKNECHT MINING

77963 Schwanau Germany Phone +49 7824 302-0 Fax +49 7824 302 3528 mining@herrenknecht.com www.herrenknecht.com

